

CARBON SENSOR Zirconia Tip

Operations Manual

Carbonseer-M[™]
QuickSilver[™]

Version# 14



Manual #: 027

Rev No: 14

Date: November 28th, 2017

COPYRIGHT(C)

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without prior written permission of United process Controls Inc.

DISCLAIMER:

All **zirconia oxygen sensors** manufactured by **United Process Controls Inc.** are to be used by the industrial operator under his/her direction. United Process Controls Inc. is not responsible or liable for any product, process or damage or injury incurred while using these sensors. United Process Controls Inc. makes no representation or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose.

For assistance please contact: United Process Controls Inc.

TEL: +1 513 772 1000 • FAX: +1 513 326 7090 Toll-Free North America +1-800-547-1055

upc.support@group-upc.com

www.group-upc.com

Contents

| CONGRATULATIONS! | 4 |
|--|----------|
| WARRANTY | 5 |
| UNPACKING YOUR SENSOR | 6 |
| SPECIFICATION | 7 |
| SENSOR DRAWING – CARBONSEER-M | 8 |
| SENSOR DRAWING – QUICKSILVER FAMILY | g |
| CONNECTION CABLE ASSEMBLIES | 10 |
| INSTALLATION CONSIDERATIONS | 11 |
| LOCATION CONSIDERATIONSPORT FITTING CONSIDERATIONS | 11 11 |
| REFERENCE AIR INSTALLATION | 12 |
| RECOMMENDED INSERTION/REMOVAL PROCEDURE | 13 |
| MAINTENANCE | 13 |
| SENSOR BURNOFF | 13 |
| FURNACE BURNOUT | 16 |
| ELECTRODE IMPEDANCE TEST | 17 |
| APPENDIX A: TROUBLESHOOTING YOUR SENSOR | 18 |
| REFERENCE AIR CHECK | 18 |
| BURNOFF CHECK | 19 |
| IMPEDANCE CHECK | 19 |
| SIGNAL LEVEL CHECK | 20 |
| PROCESS FACTOR CHECK | 20 |
| FURNACE CHECK | |
| SENSOR REPLACEMENT | 21 |
| CARBON POTENTIAL VS. SENSOR MV OUTPUT @ TEMPERATURE(S) GRAPH | 22 |
| CARBON POTENTIAL VS. SENSOR MV OUTPUT @ TEMPERATURE(S) DATA | 23 |
| DEW POINT VS. SENSOR MV OUTPUT @ TEMPERATURE(S) DATA | 25 |

CONGRATULATIONS!

You have purchased the finest oxygen sensor on the market. To realize the capabilities of this superb device, please observe the recommendations in this instruction manual.

Important

When the sensor is placed into service, please send the enclosed postage-paid warranty registration card. In the unlikely event that your sensor fails prematurely, please follow these directions in order to expedite your claim:

- 1. Carefully fill out the claim form, giving as much information as possible about the sensors conditions of use and failure to help accelerate your claim and help us improve our product.
- 2. Call UPC for an RMA number Tel: 513 772 1000
- 3. Enclose the claim form with the sensor intact and in the original packaging and return to:

United Process Controls 8904 Beckett Road West Chester, OH 45069

WARRANTY

There are no warranties, expressed or implied, including the warranties of merchantability and fitness for use, made by the exclusive distributor or representative for zirconia carbon sensors, except the expressed warranty against defects in material and workmanship described below.

United Process Controls Inc. (UPC), as manufacturer, warrants above to be free from defects in material and workmanship under normal use and service. UPC's obligation under this warranty is limited to replacing or repairing, at its option, zirconia carbon sensors herein listed, should failure occur within the warranty period. If premature failure occurs, the sensor, along with warranty claim form must be returned in the original shipping container to UPC. Upon receipt at UPC an examination shall disclose to its satisfaction the sensor to have been thus defective, at which time action will be taken.

There will be no applicable warranty in the event of breakage resulting from thermal or mechanical shock. Additionally, there will be no applicable warranty to a sensor which has been subject to misuse, negligence or accident. This warranty only applies to sensors being used at temperatures below 1850°F. At temperatures above 1850°F, the warranty is prorated as shown below. Any sensor is covered by the usage warranty as indicated from the date of installation

| - | |
|-----------------------|-----------------|
| Operating Temperature | Warranty Length |
| Less than 1850°F | 12 months |
| 1850-1950°F | 6 months |
| 1950-2050°F | 3 months |
| Above 2050°F | No warranty |

This warranty will not be honored unless the warranty card is filled out and returned to UPC and only if installation is accomplished according to UPC's specifications and procedures as described in operating/instruction manuals. UPC shall in no way be liable for special or consequential damages.

UNPACKING YOUR SENSOR

Your sensor contains ceramic parts which can withstand high temperatures and harsh environments. These ceramics are also very fragile and the sensor must be handled with the utmost care from the time it is unpacked. Your sensor is shipped from United Process Controls Inc. in a package designed specifically to ensure the sensor's safety in transit to you. This package should be retained to facilitate any potential return of the sensor to UPC. Please note that the package consists of an outer box and two foam pads which support the sensor.

Follow these steps to remove sensor:

- 1. Place package on flat surface.
- 2. Cut tape from top of outer box.
- 3. Remove top layer of foam.
- 4. Carefully remove sensor.
- 5. Reassemble empty pack and hold for possible reshipment.
- Remember to fill out the registration card and drop it in the mail when you install your sensor. This extends your warranty to be the time in the furnace so that "shelf time" is not included.
- If your sensor is not operating properly, please contact your Local UPC representative before removing the sensor. There may be trouble shooting technique only accomplished while the sensor is still installed to alleviate the problem.

| Each page | ack coi | ntains | the | follo | wing: |
|-----------|---------|--------|-----|-------|-------|
|-----------|---------|--------|-----|-------|-------|


| Statement of Carbon Sensor Accuracy |
|-------------------------------------|
| Sensor Assembly |
| Operating Manual |
| Warranty Registration Card |
| Additional Fittings & Parts |
| |


On your sensor's head is the sensor type, part number, and serial number. Please refer to the Sensor Drawing which will show additional fittings and accessories.

SPECIFICATION


| Carbon Potential Range | 0.10% to 1.4% |
|--------------------------------|--|
| Output in normal heat treating | 1000 to 1200 mV DC |
| Normal operating temp | 1400°F to 1850°F *SEE WARRANTY CARD* |
| MIN operating temp | 1150 °F |
| Sensor cover temp limit | 200 °F max. |
| Sensitivity | 0.02 mV or .0025% C |
| Accuracy | ±0.03% C |
| Stability | ±1 mV over sensor life |
| Response time | Less than 1 second |
| Impedance | Less than 6 K ohm |
| Sensor construction | Stabilized zirconia solid electrolyte; patented alloy electrode |
| Sensor thermal shock | Caution is advised, outer alloy sheath protects ceramic zircon tube. |
| Sensor Life | About 2 years with normal use |
| Warranty | 1 year usage, non-prorated |
| Serviceability | No field service required, rebuildable at factory with substantial savings |
| Reference air requirement | 0.2 to 0.5 MAX SCFH filtered air *SEE REFERENCE AIR INSTALLATION* |

SENSOR DRAWING - CARBONSEER-M





SENSOR DRAWING - QUICKSILVER FAMILY



CONNECTION CABLE ASSEMBLIES

All new installations will require the purchase of an installation cable. Connection cables can be orders in preassembled, 10ft increments (10ft, 20ft... 100ft), for the EMF and Thermocouple sensor outputs. Using the table below, pick your sensor type, desired length (in Feet), and sensor thermocouple type.

CA1 = Carbonseer-M & Quicksilver Sensors (FC2, FC3, FC5, FC6, FC7, FC8)



| Cable Part # | | | | | | | | | | | |
|--------------------------|-----|-----|----|----|--|--|--|--|--|--|--|
| CAX-XX-Y-Z | CAX | -XX | -Y | -Z | | | | | | | |
| Sensor Cable Type | | | | | | | | | | | |
| Carbonseer & QuickSilver | CA1 | | | | | | | | | | |
| Cable Length | | | | | | | | | | | |
| FT | M | | | | | | | | | | |
| 10 3 | 3.0 | 10 | | | | | | | | | |
| 20 6 | 5.1 | 20 | | | | | | | | | |
| 30 | 9.1 | 30 | | | | | | | | | |
| 40 1 | 2.2 | 40 | | | | | | | | | |
| 50 1 | 5.2 | 50 | | | | | | | | | |
| ТС Туре | | | | | | | | | | | |
| NO Thermocouple | | | -X | | | | | | | | |
| Thermocouple Type B | | | -B | | | | | | | | |
| Thermocouple Type K | -K | | | | | | | | | | |
| Thermocouple Types R & S | -RS | | | | | | | | | | |
| Modification | | | | | | | | | | | |
| (BLANK FOR STANDARD BUI | LD) | | | | | | | | | | |

^{*}Longer lengths are available

^{*}Example: FC60600S QuickSilver, Type S thermocouple, 80ft cable is required: CA1-80-RS

INSTALLATION CONSIDERATIONS

Remember these considerations when installing your sensor.

LOCATION CONSIDERATIONS

- Locate sensor near parts/work zone to get a meaningful reading.
- Locate sensor near furnace control thermocouple if possible.
- Locate sensor to avoid unnecessary close contact with heat sources (radiant tubes, heating elements) or fans.
- Locate sensor to avoid direct contact with inlet flow of carrier gas.
- Installation depth, the sensor should extend 2" 6" (5 15 cm) beyond the hot face wall of the furnace.
 - Installations that exceed the 6" (15 cm) depth beyond the hot furnace wall will have an increase in sag (creep). Over time this will cause the sensor to fail prematurely.
- Locate sensor in the upper 1/3 of work zone if possible.
- ➤ If installing the sensor in areas which vibration may occur (e.g. in furnace covers or fan assemblies), the sensor must be inserted into a protection tube with mineral fiber packing around the sheath as a damper.


PORT FITTING CONSIDERATIONS

- Models are shipped with additional fittings as shown in the Sensor Drawings. Use the fittings that best suit your needs.
- ➤ Install sensor in furnace through an access hole with minimum of 1½" diameter.
- Assure center lines of access hole and pipe coupling are concentric for correct line up.
- Assure gas-tight weld of pipe coupling to steel furnace shell.
- Assure connections on ALL external fittings adjacent to sensor are gas-tight.
- Teflon tape is preferred to other pipe dope compounds for sealing.

REFERENCE AIR INSTALLATION

In order for your sensor to function properly, reference air (20.9% O₂) must be supplied to the inner zirconia electrolyte tip. A .13 NPTM relief valve(opening pressure .09-20 psi) has been added to the head of the sensor to protect from over pressurizing the sensor and also allows accurate flow to the tip of sensor. The flow and quality of the ref air is critical for very important reasons:

- 1. Carbon potential (C_p) and O₂ calculations
- 2. O₂ leaks into the process, lowering the Sensor mV signal and artificially lowering C_D levels
- 3. The reference air flow must be between 0.2-0.5 SCFH with a reference air pressure (P_R) of 1.0-3.0 inH₂O and equal to or less than the process pressure (P_P).
- Reference air must be filtered free of contaminants and water in order to eliminate contaminants from reaching the inner electrode, impeding the sensor output.



The process pressure (P_p) must match the ref air pressure (P_r) or be slightly greater in order to prevent false High levels of O_2 in the process. High levels of O_2 will correlate to low C_p levels and high Dew Point temperatures.

RECOMMENDED INSERTION/REMOVAL PROCEDURE

- Mark the sheath of the sensor in 1" increments using a permanent marker.
- Insert the (Teflon tape) coated NPT body of the compression fitting into the furnace port and tighten accordingly ensuring a gas-tight seal.
- Place the CPI fitting and ferrule over the body of the sensor.
- Insert the tip of sensor into furnace port 6" deep initially to fully support the sensor. Allow the tip to heat up for 5 minutes.
- Insert carefully and slowly in one motion at 1/2" per second MAX. Use the 1" markings as a visual aid while inserting the sensor. If you are inserting at the correct rate, the 1" markings will insert every 2 seconds.
- Once the sensor is inserted to the desired depth, tighten the compression fitting accordingly ensuring a gas tight seal.
- Remove in the same manner. Place the sensor in an insulated blanket, once completely removed, and allow the sensor to cool to room temperature.

MAINTENANCE

The carbon sensor which you have purchased requires no mechanical maintenance. Any attempt to dismantle it could cause irreparable damage and will invalidate the warranty.

SENSOR BURNOFF

A carbon sensor operates in a very harsh environment where carbon deposits (soot) often form on the sensor. As soot accumulates at the tip of the sensor, the sensing surface of the sensor is shielded from the furnace atmosphere. This results in false, elevated carbon readings which will cause the controller to reduce the flow of enriching gas, resulting in low carbon or decarburizing conditions.

This effect is amplified in processes using elevated carbon set points such as boost and diffuse carburizing. Additionally, the high nickel content in the protective sheath alloy, while adding resistance to high temperatures, also acts as a catalyst, accelerating the deposit of carbon on the sheath.

Fact: Over 80% of carbon sensor electrode failures are due to excessive carbon buildup at the outer electrode.

Fortunately, removal of carbon deposits is as simple as running air through the "Burnoff" fitting supplied on all United Process Controls Inc. carbon sensors.

Self-cleaning of carbon sensors using air burnoff of accumulated carbon can be done successfully if the variables involved in the process are understood. The following items all contribute to the process, in order of importance:

- amount of air added for burnoff
- atmosphere circulation around the sensor
- location and amount of carbon that has accumulated

When air is forced into the sensor burnoff system, a combustion reaction between the air and the furnace atmosphere takes place. When air is added, the combustion reaction moves completely outside of the sensor (Figure 1). This process ensures sensor duration and accuracy by removing carbon buildup on the conducting cell.




Figure 1

Removal of solid carbon is much more efficient if free oxygen is present to react with it. To judge the free oxygen level, it is necessary to interpret the sensor mV output. For example, at 1700°F, the following values apply:

| O ₂ mV | %O ₂ |
|-------------------|-------------------------|
| 1150 | 9.9 x 10 ⁻¹⁹ |
| 700 | 3.6 x 10 ⁻¹¹ |
| 100 | 0.43 |

Table 1

A lower mV reading from the sensor indicates how much burnoff air is reaching the tip. The mV will never reach a 0 mV level with process atmosphere present but it should drop significantly.

The amount of air required in a given installation depends heavily on the amount of circulation of furnace atmosphere around the sensor. The higher the circulation velocity, the more air is required. One example noted that 20 SCFH (9400 cc/min) was not enough to overcome the atmosphere circulation, yet when the furnace fan was shut off, less than 2 SCFH (950 cc/min) was found to be adequate.

When the combustion reaction (burnoff) is centered at the sensor tip, a MAX rise of 100°F may be observed in the sensor thermocouple (T/C). Do not exceed a delta change in temperature of 100°F. Care must be taken to keep the sensor tip below 1850°, or permanent damage may result. Determination of the required flow rate of burnoff air is estimated by plotting the flow rate of air versus the sensor's mV reading.




Figure 2 shows a typical example of data used to determine the flow rate of air required for burnoff. In this situation, a flow rate of 7 - 8 SCFH would be selected because this provides a lower temperature as well as some free oxygen at the sensor tip. If the amount of air required is found to be so high that interference with product processing is

anticipated, the sensor should be relocated to a spot that will offer less impingement from the atmosphere circulation system.

Burnoff duration should be between 60-180 seconds (1 - 3 minutes). Do not let the sensor temperature rise above its maximum allowable temperature. The frequency of the operation depends upon the rate at which carbon is being accumulated. In continuous furnace applications, the burnoff process is ran 3-6 times daily, while in batch applications, the burnoff should be done at the start and end of each cycle. To verify the effectiveness of the burnoff procedure, simply remove the sensor after a burnoff and examine it.

Note: The Quicksilver sheath is made out of ½" schedule 40 material (¾" schedule 40 for the Carbonseer-M). The burn-off frequency must be enough to overcome carbon build up in the region around the substrate (see Figure 3), inside of the sheath. If carbon fills this space, and condenses, the sensor will fail prematurely.

Adjust burnoff frequency to prevent carbon buildup in this region around the substrate




Figure 3

FURNACE BURNOUT

Continuous operation at high carbon levels and temperatures will cause damage to most furnace components, including your sensor. It is recommended that frequent "gentle" furnace burnouts be conducted to avoid the cumulative effects of deposited carbon on furnace components. "Gentle" burnouts are normally conducted at 1500°F and can be monitored for completion by assuring that the carbon sensor output drops to

200 mV and increases to no more than 250 mV in the 15 minutes after burnout air is discontinued.

ELECTRODE IMPEDANCE TEST

It is important to track sensor impedance over a period of time to help determine the replacement schedule for the sensor. A high impedance (>50 k Ω) indicates that the electrode contact on the sensor's zirconia has deteriorated to a level that warrants replacement.

High sensor impedance results in erratic output from the sensor and an eventual failure of the electrode connection on the process side of the zirconia ceramic. This deterioration is more of a factor in highly reducing atmospheres where it may be necessary to check the impedance at least once a month. Under light reducing, annealing or brazing operations, the impedance may not have to be checked unless there is a question about the sensor's performance.

Typical impedance readings for a new sensor are less than 1 k Ω . As the sensor starts to age, the impedance will increase. Once past 20 k Ω , the sensor should be monitored more closely and above 50 k Ω , the sensor should be replaced.

When it is necessary to replace a sensor with high impedance, remove it following the instructions supplied with the sensor. Do not discard the sensor as it is often possible to rebuild the sensor, provided the ceramic parts are intact. Contact UPC for information on rebuilding your sensor.

An impedance test can only be performed if the sensor temperature is at or above $1100^{\circ}F$ with stable atmosphere present. All Marathon instruments capable of performing this test will freeze all control functions and process signals during the test. The sensor must be in a stable atmosphere condition where the mV output will not vary during the test. To test the impedance, a $10~k\Omega$ resistor is shunted across the sensor output. The sensor impedance is calculated using Formula 1.

 R_x = sensor impedance

 E_o = open circuit voltage of sensor

 E_s = shunted voltage of sensor

 R_s = shunt resistor's impedance (10 k Ω)

$$\begin{array}{c|c} \textbf{For} & R_{\mathbf{X}} \coloneqq \left(\frac{E_{\mathbf{O}}}{E_{\mathbf{S}}} - 1\right) \cdot R_{\mathbf{S}} \\ \textbf{mula} & \textbf{1} \end{array}$$

APPENDIX A: TROUBLESHOOTING YOUR SENSOR

When there is a problem making consistent product in a carburizing furnace you must consider all the possibilities before replacing the carbon sensor. In many cases, using the sensor and the control instrument to troubleshoot the problem can lead to the actual solution without replacing working equipment, incurring extended down time, sensor damage and expense.

The following table lists typical problems encountered during the operation of a carburizing furnace when carbon levels are monitored or controlled using a carbon sensor. In all cases, the last resort is to replace the sensor, particularly if nothing has been done to try and troubleshoot the problem. It is necessary to consider all the components of the control system, including the control instrument, actuators and linkages, gas supply, furnace seals, burner integrity, as well as the carbon sensor.


| Problem | Troubleshooting path |
|--|-----------------------------|
| Carbon readings are always the same or consistently | Go to Burnoff Check. |
| higher than typical carbon levels under normal furnace conditions. | |
| Carbon readings and/or Dew Point temperatures are too | Go to Reference Air Check. |
| low/high and/or do not change. | Go to Furnace Check. |
| Carbon readings are erratic or carbon level keeps | Go to Signal Level Check. |
| oscillating. | Go to Impedance Check. |
| | Go to Furnace Check. |
| Carbon readings drop drastically for short periods of | Go to Burnoff Check. |
| time. | Go to Furnace Check. |
| Carbon readings react with changes in the furnace but | Go to Process Factor Check. |
| the load case depth is heavy or light. | |
| There is no reference air flow. | Go to Reference Air Check. |
| There is no burnoff air flow. | Go to Burnoff Check. |

Table 2

REFERENCE AIR CHECK

- 1. Ensure that reference air source is providing clean room air that is free of airborne contaminates. Do not use compressed air unless it is free from oil and pressure regulated at $1.0-3.0 \text{ inH}_2\text{O}$. If in doubt about the reference air source, try an alternative source.
- 2. If reference airflow is not between 0.2 0.5 SCFH on a flow meter, ensure that airflow is getting to the sensor. Disconnect the reference air tube at the sensor and see if tube will bubble in a cup of water and flow meter is working. If bubbles are present then reference air is definitely getting to the sensor. If there is no

- flow when the tube is reattached to the sensor, the reference air tubing in the sensor is blocked. Replace the sensor.
- 3. The reference air flow must be between 0.2-0.5 SCFH with a reference air pressure (P_R) of 1.0-3.0 inH₂O and equal to or less than the process pressure (P_P).



4. The process pressure (P_p) must match the ref air pressure (P_r) or be slightly greater in order to prevent false High levels of O_2 in the process. High levels of O_2 will correlate to low C_p levels and high Dew Point temperatures.

BURNOFF CHECK

- 1. Perform a burnoff with the sensor at 1500°F minimum. The sensor temperature should increase slightly (100°F) above the ambient furnace temperature and the sensor mV should drop from pre-burnoff levels.
- Check burnoff airflow. Verify that the burnoff event is active and that the burnoff solenoid is on. Verify that airflow is being supplied to the sensor by doing the bubble test as described in "Reference Air Check."
- 3. If all of the above is correct but the sensor mV still does not drop, repeat the burnoff procedure at a more frequent interval. If after a minimum of five burn offs there is no change in the mV reading and proper response to carbon changes, remove the sensor and inspect for heavy sooting. See Sensor Replacement.

IMPEDANCE CHECK

1. Check the sensor's impedance with a minimum temperature of 1500°F. A good sensor's impedance should be between 0.1-20 k Ω . If the impedance is above 20 k Ω , the sensor electrodes are degrading and the sensor should be monitored more closely. If the levels reach 50 k Ω , the sensor should be replaced. If the impedance is good, check Process Factor or see Furnace Checks.

If the sensor impedance is high during one test and low or normal during another test, check the connections between the instrument and the sensor. If the impedance readings are still intermittent, see Sensor Replacement.

SIGNAL LEVEL CHECK

- If the carbon sensor measurement system does, in fact, disagree with alternative measurement technique (e.g. FDPRO IR analyzer, shim stock analysis), check the sensor temperature and mV readings with the Percent Carbon chart (in the back of this manual) and see Process Factor Check. If these values agree then go to the Furnace Checks.
- 2. If sensor thermocouple display on instrument is not within ±25°F of furnace control thermocouple, make sure the instrument thermocouple type is set to the same thermocouple as the sensor thermocouple. If the reading is negative, check thermocouple connections. If the reading is >2300°F, check for an open or loose connection or open thermocouple.
- 3. Check the oxygen mV reading and ensure it agrees within ± 6 mV of simultaneous readings from a digital voltmeter. Use a voltmeter with a 0.5% DC accuracy and 10 M Ω minimum input impedance. If the reading at the instrument is negative or zero, check for reversed, open or loose connections.
- 4. Connect a voltmeter directly to the sensor lead wires. When the positive sensor lead wire is disconnected from the sensor terminal block, the reading on the voltmeter should not change more than 2 mV. If the reading does change, make sure that the signal cable shield is connected at only the instrument ground and that the instrument has been properly grounded. Verify that the signal wire has not melted, been crushed or shorted between the leads, shield or ground. If the grounding and cable shield are good, verify that the instrument input is not loading down the sensor signal. Connect the sensor to another controller or change the input board on the controller. If the signal level still drops, go to the next step.
- Short the sensor mV terminals for 15 seconds. If the sensor mV does not return to its original reading, ±10 mV, within 30 seconds as measured with one voltmeter, go to the Impedance Check.

PROCESS FACTOR CHECK

- 1. Ensure that the process factor is set to an appropriate value. A typical process factor for a new sensor in a methane based endothermic gas (20% CO) would be 150. The process factor would be 128 in a nitrogen-methanol system, but this is dependent on the ratio of methanol to nitrogen. In a pure methanol atmosphere, the theoretical process factor would be 85.
- 2. Increasing the process factor will lower the calculated percent carbon and cause the controller to increase the trim gas flow to the furnace. Decreasing the

process factor will increase the calculated percent carbon and cause the controller to increase the trim air and/or decrease the trim gas. If the process factor has to be adjusted to very high (>300) or very low (<50) values, go to the Impedance Check.


FURNACE CHECK

- 1. Try to determine if changes in the sensor carbon reading occur during other events on the furnace. For example, carbon fluctuations may correspond to gasfired burners coming on during the early part of the heat cycle. This would indicate that there is a hole in a burner tube, leaking into the furnace.
- 2. An air leak or a water leak on a water jacket may cause low carbon readings.
- 3. Check actuator operation or linkage if the control stays at a 0% or 100% output with no resulting change in carbon level.
- 4. Verify that the controller is moving the actuators properly by placing the controller in manual mode and changing the output from 0% to 100%.
- 5. Verify that the endo gas, trim gas and trim air lines are opened and that manually adjusted flow meters are fully open.
- 6. Verify that trim lines are not bypassed if this feature is available.

SENSOR REPLACEMENT

- If your sensor is not working properly, please contact your Local UPC representative before removing the sensor. There may be trouble shooting technique only accomplished while the sensor is still installed
- Insert/remove the sensor at ½" per second MAX if furnace is hot and place into an insulated blanket until complete dissipation. The modularity of the Carbonseer-M makes possible to rebuild a faulty sensor.
- Ensure that the sensor sheath shows no significant accumulation of soot or other deposits.
- Make sure that the main ceramic tube of the sensor is physically intact.
- Be sure that the sensor sheath is not is not warped.
- Note the above conditions and the sensor's serial number. Call UPC for an RMA to test and possibly rebuild the sensor.


CARBON POTENTIAL VS. SENSOR MV OUTPUT @ TEMPERATURE(S) GRAPH



CARBON POTENTIAL VS. SENSOR MV OUTPUT @ TEMPERATURE(S) DATA

| | | 1400 | 1425 | 1450 | 1475 | 1500 | 1525 | 1550 | 1575 | 1600 | 1625 | 1650 | 1675 | 1700 | 1725 | 1750 | 1775 | 1800 | 1825 | 1850 | 1875 | 1900 |
|------------------|------|------|------|---------|---------|---------|----------|---------|---------|-------|---------------------|---------|--------|---------|---------|------|------|------|------|------|------|------|
| | 1.60 | | | | | | | | | | | | | | | | | | | | | |
| | 1.55 | | | | | | | | | | | | | | | | | | | | | 1219 |
| | 1.50 | | | | | | | | | | | | | | | | | | | | 1212 | 1216 |
| | 1.45 | | | | | | | | | | | | | | | | | | | 1204 | 1209 | 1213 |
| | 1.40 | | | | | | | | | | | | | | | | | 1192 | 1197 | 1201 | 1206 | 1210 |
| | 1.35 | | | | | | | | | | | | | | | | | 1189 | 1194 | 1198 | 1203 | 1207 |
| | 1.30 | | | | | | | | | | | | | | | | 1182 | 1187 | 1191 | 1195 | 1200 | 1204 |
| | 1.25 | | | | | | | | | | | | | | | 1175 | 1179 | 1184 | 1168 | 1193 | 1197 | 1201 |
| | 1.20 | | | | | | | | | | | | | 1164 | 1168 | 1172 | 1177 | 1181 | 1186 | 1190 | 1194 | 1198 |
| | 1.15 | | | | | | | | | | | | 1157 | 1161 | 1165 | 1170 | 1174 | 1178 | 1182 | 1187 | 1191 | 1195 |
| l $_{\odot}$ | 1.10 | | | | | | | | | | 1146 | 1150 | 1154 | 1158 | 1162 | 1167 | 1171 | 1175 | 1179 | 1183 | 1187 | 1192 |
| L (%C) | 1.05 | | | | | | | | | 1139 | 1143 | 1147 | 1151 | 1155 | 1159 | 1163 | 1167 | 1172 | 1176 | 1180 | 1184 | 1188 |
| N A I A | 1.00 | | | | | | | | | 1136 | 1140 | 1144 | 1148 | 1152 | 1156 | 1160 | 1164 | 1168 | 1172 | 1176 | 1180 | 1185 |
| OTE | 0.95 | | | | | | | | 1129 | 1133 | 1137 | 1141 | 1145 | 1149 | 1153 | 1157 | 1161 | 1165 | 1169 | 1173 | 1177 | 1181 |
| CARBON POTENTIAL | 0.90 | | | | | | | 1122 | 1125 | 1129 | 1133 | 1137 | 1141 | 1145 | 1149 | 1153 | 1157 | 1161 | 1165 | 1169 | 1173 | 1177 |
| ARB | 0.85 | | | | | 1111 | 1114 | 1118 | 1122 | 1126 | 1130 | 1134 | 1138 | 1142 | 1145 | 1149 | 1153 | 1157 | 1161 | 1165 | 1169 | 1172 |
| ľ | 0.80 | | | 1100 | 1104 | 1107 | 1111 | 1115 | 1119 | 1122 | 1126 | 1130 | 1134 | 1138 | 1141 | 1145 | 1149 | 1153 | 1156 | 1160 | 1164 | 1168 |
| | 0.75 | 1089 | 1093 | 1097 | 1100 | 1104 | 1107 | 1111 | 1115 | 1119 | 1122 | 1126 | 1130 | 1134 | 1137 | 1141 | 1144 | 1148 | 1152 | 1156 | 1159 | 1163 |
| | 0.70 | 1086 | 1089 | 1093 | 1098 | 1100 | 1104 | 1108 | 1111 | 1115 | 1116 | 1122 | 1125 | 1129 | 1133 | 1136 | 1140 | 1144 | 1147 | 1151 | 1154 | 1158 |
| | 0.65 | 1082 | 1085 | 1089 | 1092 | 1096 | 1100 | 1103 | 1107 | 1110 | 1114 | 1117 | 1121 | 1124 | 1128 | 1131 | 1135 | 1138 | 1142 | 1145 | 1149 | 1153 |
| | 0.60 | 1078 | 1081 | 1085 | 1088 | 1092 | 1095 | 1099 | 1102 | 1106 | 1109 | 1112 | 1116 | 1119 | 1123 | 1126 | 1129 | 1133 | 1136 | 1140 | 1143 | 1147 |
| | 0.55 | 1074 | 1077 | 1081 | 1084 | 1087 | 1091 | 1094 | 1097 | 1101 | 1104 | 1107 | 1110 | 1114 | 1117 | 1120 | 1124 | 1127 | 1130 | 1134 | 1137 | 1140 |
| | 0.50 | 1070 | 1073 | 1076 | 1079 | 1082 | 1086 | 1089 | 1092 | 1095 | 1098 | 1102 | 1105 | 1108 | 1111 | 1114 | 1118 | 1121 | 1124 | 1127 | 1130 | 1134 |
| | 0.45 | 1065 | 1068 | 1071 | 1074 | 1077 | 1080 | 1083 | 1088 | 1089 | 1092 | 1095 | 1098 | 1102 | 1105 | 1108 | 1111 | 1114 | 1117 | 1120 | 1123 | 1126 |
| | 0.40 | | 1062 | 1065 | 1068 | 1071 | 1074 | 1077 | 1080 | 1083 | 1088 | 1088 | 1091 | 1094 | 1097 | 1100 | 1103 | 1106 | 1109 | 1112 | 1115 | 1118 |
| | 0.35 | | | | | | | | | | | | | 1086 | | | | | | | | |
| | 0.30 | | | | 1054 | | | | | | | | | | | | | | | | | 1098 |
| | 0.25 | | | | | 1048 | | | | | | | | | | | | | | | | 1086 |
| | 0.20 | | | | | | 1039 | | | | | | | 1054 | | | | | | | | |
| | 0.15 | | | | | | | 1028 | 1030 | 1032 | 1034 | 1035 | 1037 | 1039 | 1041 | 1043 | 1045 | 1047 | 1048 | 1050 | 1052 | 1054 |
| | | | * Da | ta only | / valid | with ca | arrier g | gas con | npositi | on CO | + CO ₂ : | = 20% a | and Al | SI 1010 |) Steel | | | | | | | |

DEW POINT VS. SENSOR MV OUTPUT @ TEMPERATURE(S) GRAPH



DEW POINT VS. SENSOR MV OUTPUT @ TEMPERATURE(S) DATA

| | | | | | | | | TEN | ИPERA | TURE | (°F) | | | | | | |
|----------------|-----|------|------|------|------|---------|---------|--------|-------|--------|--------------------|------------|------|------|------|------|------|
| | | 1400 | 1450 | 1500 | 1550 | 1600 | 1650 | 1700 | 1750 | 1800 | 1850 | 1900 | 1950 | 2000 | 2050 | 2100 | 2150 |
| | 90 | 1041 | 1035 | 1028 | 1021 | 1015 | 1008 | 1002 | 995 | 989 | 982 | 976 | 969 | 962 | 955 | 949 | 942 |
| | 85 | 1048 | 1042 | 1036 | 1029 | 1023 | 1017 | 1010 | 1004 | 998 | 991 | 985 | 978 | 972 | 965 | 959 | 952 |
| | 80 | 1055 | 1049 | 1044 | 1037 | 1031 | 1025 | 1019 | 1013 | 1007 | 1000 | 994 | 988 | 981 | 975 | 969 | 962 |
| | 75 | 1063 | 1057 | 1051 | 1045 | 1040 | 1034 | 1028 | 1022 | 1015 | 1009 | 1004 | 997 | 991 | 985 | 979 | 973 |
| | 70 | 1071 | 1065 | 1060 | 1054 | 1048 | 1042 | 1037 | 1031 | 1025 | 1019 | 1013 | 1007 | 1002 | 996 | 990 | 984 |
| | 65 | 1078 | 1073 | 1068 | 1062 | 1057 | 1051 | 1046 | 1040 | 1035 | 1029 | 1023 | 1018 | 1012 | 1006 | 1000 | 995 |
| | 60 | 1086 | 1081 | 1076 | 1071 | 1065 | 1060 | 1055 | 1050 | 1044 | 1039 | 1033 | 1028 | 1022 | 1017 | 1011 | 1006 |
| | 55 | 1094 | 1090 | 1085 | 1080 | 1074 | 1069 | 1064 | 1059 | 1054 | 1049 | 1044 | 1038 | 1033 | 1028 | 1022 | 1017 |
| | 50 | 1103 | 1098 | 1094 | 1089 | 1083 | 1079 | 1074 | 1069 | 1064 | 1059 | 1054 | 1049 | 1044 | 1039 | 1034 | 1029 |
| | 45 | 1111 | 1107 | 1102 | 1098 | 1093 | 1088 | 1084 | 1079 | 1074 | 1070 | 1065 | 1060 | 1055 | 1050 | 1045 | 1041 |
| t (°F) | 40 | 1120 | 1116 | 1112 | 1107 | 1103 | 1098 | 1094 | 1089 | 1085 | 1080 | 1076 | 1071 | 1067 | 1062 | 1058 | 1053 |
| Poin | 35 | 1129 | 1125 | 1121 | 1116 | 1112 | 1108 | 1104 | 1100 | 1096 | 1091 | 1087 | 1083 | 1078 | 1074 | 1070 | 1065 |
| Dew Point (°F) | 30 | 1137 | 1134 | 1130 | 1126 | 1122 | 1118 | 1114 | 1110 | 1106 | 1102 | 1098 | 1094 | 1090 | 1086 | 1082 | 1077 |
| | 25 | 1147 | 1143 | 1140 | 1136 | 1132 | 1129 | 1125 | 1121 | 1118 | 1114 | 1110 | 1106 | 1102 | 1098 | 1094 | 1090 |
| , | 20 | 1156 | 1153 | 1150 | 1146 | 1143 | 1139 | 1136 | 1132 | 1129 | 1125 | 1122 | 1118 | 1115 | 1111 | 1107 | 1104 |
| | 15 | 1166 | 1163 | 1160 | 1156 | 1153 | 1150 | 1147 | 1144 | 1141 | 1137 | 1134 | 1131 | 1127 | 1124 | 1120 | 1117 |
| | 10 | 1175 | 1172 | 1170 | 1167 | 1164 | 1161 | 1158 | 1155 | 1152 | 1149 | 1146 | 1143 | 1140 | 1137 | 1134 | 1130 |
| | 5 | 1185 | 1183 | 1180 | 1176 | 1175 | 1172 | 1170 | 1167 | 1164 | 1161 | 1159 | 1156 | 1153 | 1150 | 1147 | 1144 |
| | 0 | 1195 | 1193 | 1191 | 1189 | 1186 | 1184 | 1182 | 1179 | 1177 | 1174 | 1172 | 1169 | 1167 | 1164 | 1161 | 1159 |
| | -5 | 1206 | 1204 | 1202 | 1200 | 1198 | 1196 | 1194 | 1191 | 1190 | 1187 | 1185 | 1183 | 1181 | 1178 | 1176 | 1173 |
| | -10 | 1217 | 1215 | 1213 | 1211 | 1210 | 1208 | 1206 | 1204 | 1203 | 1201 | 1199 | 1197 | 1195 | 1193 | 1191 | 1189 |
| | -15 | 1227 | 1226 | 1225 | 1223 | 1221 | 1220 | 1218 | 1217 | 1215 | 1214 | 1212 | 1210 | 1209 | 1207 | 1205 | 1203 |
| | -20 | 1238 | 1237 | 1236 | 1235 | 1234 | 1233 | 1231 | 1230 | 1229 | 1227 | 1226 | 1225 | 1224 | 1222 | 1221 | 1219 |
| | | | | * | Data | only va | alid wi | th gas | comp | ositio | n H ₂ + | $H_20 = 4$ | 10% | | | | |

Reach us at www.group-upc.com

United Process Controls brings together leading brands to the heat treating industry including Atmosphere Engineering, Furnace Control, Marathon Monitors and Process-Electronic and Waukee Engineering.

We provide prime control solutions through our worldwide sales and services network with easy-toaccess local support.

UNITED PROCESS CONTROLS INC. 8904 Beckett Rd., West Chester, OH 45069 USA

+1-513-772-1000 | Fax: +1-513-326-7090

TOLL-FREE North America +1-800-547-1055

E-mail: upc.sales@group-upc.com









